## Call transfer

**Attended transfer:**

1. Press key or Xfer soft key during the active conversation, the call is put on hold.
2. Dial the second telephone number.
3. When the call is answered, then press key or Xfer soft key to complete the operation.

**Blind transfer:**

1. Press key or Xfer soft key during the active conversation, the call will be on hold.
2. Then enter the 2nd telephone number and press key or Xfer soft key.

## Call forward

1. Press Menu > Features > Call Forward.
2. Select the line, the type of forward, enter the destination number and status and OK.

## Call Mute

1. Press to Mute the microphone during the call.
2. Press again to un-mute the conversation.

## Call list

1. Press key or Menu > CallLog > Local Call Logs.
2. Scroll through the list using .
3. To dial an entry, press Dial soft key or pickup handset or press or .

## Phonebook

**Access phonebook:**

1. Press or Contact soft key or Menu > PhoneBook > Local Contacts.
2. Select All Contacts or other group.
3. To dial an entry, press Dial soft key or pickup handset or press or .

**Add new entry:**

1. Press Contact soft key, Press All Contacts or other group > Press Add.
2. Enter name and number and press OK soft key.

## Redial

1. Press redial a call number.

## Do not disturb

1. Press DND soft key, and enable the device do not disturb mode.
2. Or press Menu > Features > DND, and select the Mode and Type, and press OK soft key.

## Voice mail

1. To access your voice mailbox, press or Menu > Message > Voice Message, number of messages will be indicated if provided by your server or pbx.
2. Select the line and press Play to call.

## Bluetooth

1. Press Menu > Basic > Bluetooth.
2. Press OK soft key to enter the bluetooth open interface. After opening, press Scan soft key to display the list of bluetooth scanned. Select any device and press connect.

## Wi-Fi

1. Plug the Wi-Fi Dongle. Press Menu > Basic > WLAN.
2. Press OK soft key to enter the WLAN open interface. After opening, press Scan soft key to display the list of Wi-Fi scanned.
3. Press Enter soft key to enter the available Network, select the wireless network, press the Connect soft key and enter the password to connect.



CannonVoIP

Website: cannonvoip.com
Email: info@cannonvoip.com
Tel: 888-973-0515 Local: 817-973-1570
Add: 4108 Amon Carter Blvd, Ste 208
Fort Worth, TX 76155




CannonVoIP

V3.1






# VoIP-6

## Quick Installation Guide



Cannon VoIP
cannonvoip.com | 888-973-0515


## Packaging list



IP Phone



Handset


Handset Cord


Ethernet Cord


Quick Installation Guide


Stand


Power Adapter
(Included packaged separately)


Wi-Fi Dongle

## Screen icon

- In hands-free mode
- In headset mode
- In handset mode
- Mute activated
- Ringer off
- Call is on hold
- Bluetooth device paired connection
- Do not disturb activated (Red)
- New SMS
- New VM Messages
- Voice Quality Level of call
- Forward call(s)
- Missed call(s)
- Received call(s)
- Dialed call(s)
- Internet connected
- Internet is disconnected
- No IP address
- Wireless network connected
- Wireless network disconnected
- Wireless network failure

## Keys features

Line keys

Soft keys

Message waiting indicator

Left and right navigation keys
Up navigation key, Shortcut to call log
Down navigation key, Shortcut to Status
OK key, Shortcut to Menu

Hold key, Hold/Resume the call

Call transfer key

Conference key

DSS Keys, It can be set as line key /function key/speed dial key, etc.

Page-Jump key, It can switch the vice screen DSS pages

Phonebook key

Call logs key

Voice messages key

Headset key, Activate/deactivate Headset

Redial key, Access to redial the last record

In idle mode: ringer off
In communication mode: mute/ un-mute a call

In idle mode or during ringing: increase or decrease ringer volume
In communication: increase or decrease
earpiece, headset or hands-free volume

Hands-free key, Activate/deactivate hands free


Long press to lock keypad.
Enter PIN to unlock keypad



## Installation the device

Please follow the instructions in below picture to install the device.

- **Bracket desktop installation**




- **Wi-Fi dongle installation**


Plug the Wi-Fi dongle into the USB port on the back of the phone (port 1 in the diagram below). Then press Menu > Basic > WLAN to connect to your wireless network.


USB port (back of phone)

**Connecting to the Device**

Please connect power adapter, network, PC, handset, and headset to the corresponding ports as described in below picture.

① USB port: connect USB device (USB flash disk, WIFI Dongle)
② Power port: connect the power adapter.
③ Network port: connecting local area network or Internet.
④ PC port: the network port connect to the computer.
⑤ Headset port: connect headset.
⑥ Handset port: connect IP Phone handset.




## Language setting

1. Press Menu key > Basic > Language.
2. Select the desired language and press OK soft key.

## Making a call

1. **Pre-dialing**: enter the phone number and pick up the handset.
2. **Direct dialing**: lift the handset and enter the phone number.
3. **Handsfree**: enter phone number and press or vice versa.
4. **Headset:** enter phone number and press or vice versa.
5. **Designated line:** press line key, enter phone number and press dial key.

## Accepting a call

1. **With the handset**: pick up the handset.
2. **With a headset**: press .
3. **With the handsfree**: press .

## Putting a call on hold

1. Press key or Hold soft key, caller is put on hold.
2. To retrieve the call press key or Resume soft key.

**Note**: with more than one active call, select desired call with the navigator keys and use the corresponding soft key to hold or resume.

## 3-party conference

1. Once in line with 1st caller, press key or Conf soft key, 1st caller is put on hold.
2. Then call the 2nd number.
3. After, 2nd call is established, press key or Conf soft key to set up the conference.